

Kwik Jam Door Installation Instructions:



1. Remove the inside door trim on the lock side of the door jamb.

2. Remove the screws that retain the strike plate, and check for excessive damage (i.e. rotten wood, etc.)



3. Carefully slide "Kwik Jam™" over the door jamb frame and into place between the interior wall next to the strike side jamb. (jamb side with the lock holes)
NOTE: In some cases removal of a shim may be necessary.



4. Next, line up "Kwik Jam™" so that the long slots (inside edge/room side) meet evenly with the door jamb strike holes while making sure that the "Kwik Jam" slides clearly between the jamb and door seal (slight bending may be needed).



"Kwik Jam™" is designed with custom easy to install screws for quick installation, although some installations may require the pre-drilling of the mounting holes depending on the age and condition of the installation area.

5. Hold flush to existing door jamb and using a short screw, mount the "Kwik Jam™" with one of the upper holes, tightening enough for door clearance.

6. While gently pushing "Kwik Jam™" at the bottom edge, close the door and check for correct lock contact. When satisfied, insert the 3 3/4 inch screws (or special size fasteners of your choosing) to tighten and complete the installation.

